

HNC-8 System Commissioning Manual (Grinding System)

V2.4 Version

Introduction

The manual may help you to quickly get familiar with the HNC-8 system, providing detailed information about commissioning, programming or application methods. Any updates or modification of the manual is not allowed without the written permission of Wuhan Huazhong Numerical Control Co., LTD (hereafter referred to as "HCNC"). Without HCNC's authorization or written permission, any units or individuals are not allowed to modify or correct the manual. HCNC will not be responsible for any losses thus incurred to customers.






In this manual we have tried as much as possible to describe all the various matters concerning of the system. However, we cannot describe all the matters which must not be done, or which cannot be done, because there are so many possibilities. Therefore, matters which are not especially described as possible in this manual should be regarded as "impossible" or "not allowed".

Copyright of the manual should be reserved by HCNC. Any units and individuals' publication or duplication should be deemed as illegal behavior and we will hold them accountable.

Please favor me your instruction for shortages and inadequacies of the manual.



Note

-  As to notes such as "Limitations" and "Usable functions", the specification provided by the machine tool manufacturer is superior to the manual. Please conduct dryrun before actual machining and confirm machining program, tool compensation volume and workpiece offset, and so on.
-  Please explain matters which are not described in the manual as "Infeasible".
-  The manual is prepared on the condition that all functions are configured. Please make a confirmation according to the specification provided by the machine tool manufacturer in use.
-  For relevant instructions for machine tools, please refer to the specification provided by the machine tool manufacturer.
-  Usable screens and functions differ with different NC systems (or versions). Please be sure to confirm specifications before use.

Contents

Introduction	i
1 HNC-808DG Grinding System Function Introduction	1
2 Commissioning Steps	2
2.1 Bus Connection	2
2.2 Parameter Adjustment and Testing	3
2.2.1 Whole Structure of Parameter	3
2.2.2 NC Parameter	5
2.2.3 Machine Tool User Parameters	7
2.2.4 Channel Parameter	10
2.2.5 Coordinate Axis Parameter	14
2.2.6 Device Interface Parameter	20
2.3 PLC Commissioning	24
2.3.1 HNC-8 PLC Structure	24
2.3.2 Working Principle of PLC Interface Signal	25
2.3.3 PLC Specification	27
2.3.4 PLC Switch File and P Parameter	27
2.3.5 Common PLC Module	28
2.3.6 PLC Point	32
2.3.7 M Code	34
2.4 Common G Code Command	35
2.4.1 G10 Command	35
2.4.2 Stop Read-ahead	35
2.4.3 Other Codes	35
2.5 New Functions in Version 2.40.01	36
2.5.1 Technology Encryption Function	36
2.5.2 System Display Manual	37
2.5.3 Backup and Restore of Grinding Data	38
2.5.4 Insert Cycle	41
2.5.5 Grinding Card Interface Refreshing	43
2.5.6 Oblique Axis	44
2.5.7 G153/G154 Axis Oscillation Function	45
2.5.8 Workpiece Coordinate System Zero Translation Commands G155, G156	46
3 Grinding Technology Introduction	47
3.1 Canned Cycle	47
3.1.1 Plunge Grinding	47
3.1.2 Longitudinal Grinding	53
3.1.3 Grinding Wheel Dressing	56
3.1.4 End Face Positioning	59
3.1.5 Wheel End face Dressing	61
3.2 Process Card	62
3.2.1 Commonly Used Parameters	62
3.2.2 Parameters Of Grinding Wheel	64
3.2.3 Parameters of Measuring Instrument	67
3.2.4 Parameters Of Plummer Block	68
3.2.5 Custom Macro Variable	74


1 HNC-808DG Grinding System Function Introduction

SN	Function	808DG
1	Handwheel simulation	The rotation speed in handwheel replaces the G01 speed. It takes effect when the program runs automatically.
2	Handwheel insertion	Namely "Handwheel interruption", the handwheel interruption amount is superimposed on zero of the currently used coordinate system. It is superimposed on all zero until the interruption amount is cleared.
3	PMC	Programmable Machine Control. Servo axis, but it does not participate in interpolation operation. It has absolute command and relative command. Auxiliary precise control
4	C/S switching	Rotary axis control. Both angle displacement command and speed rotation command can be executed. Selection of grinding head control. It is applicable to thread and screw grinding, crank shaft, cam and gear grinding, etc.
5	Built-in oscilloscope	Built-in speed loop, position loop and notch filter, easy for commissioning.
6	Grating ruler	Support absolute encoder, increment grating. Manufacturer: Heidenhain, Fagor
7	SSTT sampling	Assist sampling commissioning, monitoring and diagnosis
8	★Oblique axis	X axis is the oblique axis and Z axis is regular. Generally, the inclined angle between axes X and Z is 30°. After this function is enabled, Cartesian coordinate system is adopted for programming, namely normal rectangular programming.
9	★Multichannel	808DG has integrated double channels and can be directly used. Used for truss and other schemes of which logical relationships require multi-channel control.
10	PLC online programming	PLC online programming of NC. Also support online debugging of connection of upper and lower microcomputers of PC and NC.
11	★Multigroup D/A	Multi-group D/A, A/D. It is applicable to headstock, frequency conversion wheel, or multigroup frequency conversion output. It can also collect analog voltage and analog current and can be used for monitoring.
12	★Electronic gearbox	Electronic transmission ratio control replaces mechanical transmission ratio. Used for gear machining.
13	★Crankshaft grinding	Tangency point following. The main rotating parts of the engine. After connecting rod is installed, it can change vertical (reciprocating) motion of connecting rod into cyclic (rotational) motion
14	★Cam grinding	Tangency point following. A part in the piston engine. It functions on controlling ON and OFF of air valve
15	★ Video tool setting of grinding wheel	Images collected by HD camera are displayed in the tool compensation interface. Assist observation.
16	★Multiaxis synchronous control	Applicable to complex and high-end grinding.
17	★Thermal error compensation	High precision grinding requirement, thermal error compensation.


2 Commissioning Steps

2.1 Bus Connection

System, drive and I/O unit are connected in series in proper order.



View devices detected in System Set-Config. Device interface parameters should be set to correspond to the detection sequence one by one.



2.2 Parameter Adjustment and Testing

2.2.1 Whole Structure of Parameter

(1) Assignment of parameter numbers

The number (ID) allocation of various parameters of the HNC-8 CNC system is shown in the following table:

Type	ID	Description
NC parameter	000000 - 009999	Occupy 10000 ID numbers
Machine user parameter	010000 - 019999	Occupy 10000 ID numbers
Channel parameter	040000 - 049999	Divided by channel. Each channel occupy 1000 ID numbers
Coordinate axis parameter	100000 - 199999	Divided by axis, each axis occupy 1000 ID numbers
Error compensation parameter	300000 - 399999	Divided by axis, each axis occupy 1000 ID numbers
Device interface parameter	500000 - 599999	Divided by device, each device occupy 1000 ID numbers
Data table parameter	700000 - 799999	Occupy 100000 ID numbers

- NC parameters are the basic parameters of the CNC system, which are used to set parameters of interpolation cycle and operation resolution.
- Machine user parameters are used to set machine tool structure, number of channels and other parameters, such as whether it is a lathe or a milling machine, and the channels used.
- The path through which the channel executes the interpolation movement. Different channels can perform different interpolation motions, and do not affect each other. Dual channel means that two different interpolation motions can be executed at the same time. Channel parameters are used to set the relevant parameters of each channel.
- Coordinate axis parameters are used to set the relevant parameters of the logical axis used in the channel.
- Error compensation parameters are used to set the backlash, pitch error and other related error compensation parameters.
- Device interface parameters are used to set the relevant parameters of physical devices such as axes and I/O.
- Data table parameters are used to set data tables of error compensation, temperature correspondence, etc.

(2) Data type of parameter

The data types of HNC-8 CNC system parameters include the following:

INT4: The parameter value can only be an integer.

BOOL: The parameter value can only be 0 or 1.

REAL: The parameter value can be an integer or a decimal.

STRING: The parameter value is a string of 1 to 7 characters.

HEX4: The parameters are input and displayed in hexadecimal numbers.

ARRAY: The parameters are input and displayed in the form of an array, and each data is separated by "," or ".".
The value range of the array elements is 0 to 127.

(3) Parameter access level

- The parameters of each level must be modified and saved after entering the corresponding password and logging in.
- Modification of low-level parameters is allowed after high-level login.
- The curing parameters (access level 5) are not allowed to be modified manually, and are automatically configured by the CNC system (cured at the factory).
- The parameter access levels are shown in the following table:

Access level	Object-oriented	Identity
1	General user	ACCESS_USER
2	Machine manufacturer	ACCESS_MAC
3	CNC controller manufacturer	ACCESS_NC
4	Administrator	ACCESS_RD
5	Curing	ACCESS_VENDER

(4) Parameter activation

There four activation modes of HNC-8 CNC system parameters.

- Save_active: Parameter modification takes effect after SAVE key is pressed.
- Immediate_active: Parameter modification takes effect immediately (mainly used for servo parameter adjustment).
- Reset_active: Parameter modification takes effect after being saved and RESET key is pressed.
- Restart_active: Parameter modification takes effect after being saved and CNC controller is restarted.

2.2.2 NC Parameter



参数号	参数名	参数值	生效方式
000018	系统时间显示使能	1	保存
000020	报警弹窗自动显示使能	0	保存
000022	图形预览使能	0	保存
000024	G代码行号显示方式	3	保存
000025	尺寸公制/英制显示选择	1	保存
000026	位置值小数点后显示位数	3	保存
000027	速度值小数点后显示位数	1	保存
000028	转速值小数点后显示位数	0	保存
000030	进入屏保等待时间(min)	0	保存

最大值: 1
默认值: 1
最小值: 0

说明: 该参数用于设定数控系统人机界面是否显示当前系统时间。
0: 不显示系统时间
1: 显示系统时间

\$1

保存 输入口令 置出厂值 查找 自动偏置

000018	System time display	0: is disabled; 1: is enabled
000020	Automatic display of alarm pop-up window	0: is disabled; 1: is enabled
000023	F feedrate display mode	Selection of display of actual, command and programming speed. When F jitters, view the parameter and change to 1 command or 2 programming
000024	G code line number display mode	0: G code line number is not displayed; 1: G code line number is only displayed on editing interface; 2: G code line number is only displayed on programming running interface; 3: G code line number is displayed both on editing interface and program running interface.
000026	Decimal places of positional value	Recommend to set to 3
000027	Decimal places of speed value	Set based on grinding requirements
000028	Decimal places of rotation speed value	Set based on actual requirements
000030	Screensaver entry waiting minutes	Set based on actual requirements. When 0 is set, the system will never enter screen

参数号	参数名	参数值	生效方式
000060	系统保存刀具数据的数目	10	复位
000064	刀具磨损累加使能	1	复位
000065	直径显示使能	0x1	重启
000066	半圆心理论与实际的偏差允许值(...)	0.000	复位
000071	解释器周期最大解释段数	20	保存
000072	是否关闭加工时间显示	0	保存
000073	跟踪误差滞后周期	1	复位
000077	程序预览最大运行时间(秒)	0	保存
000080	日志文件保存类型	2	重启

说明：该参数用于设定刀具表中保存刀具数据（刀偏，磨损，半径，刀尖方位，长度等）的刀具把数，该值要大于等于各个通道内的刀具总和。

最大值：1000
默认值：100
最小值：0

\$1

000061	Number of T command tool offset compensation number digits	Generally it is 2
000064	Tool wear accumulation Enable	Generally it is 1
000072	Whether machining time display is closed	Display in the bottom right corner of the interface and set as needed

2.2.3 Machine Tool User Parameters

参数号	参数名	参数值	生效方式
010000	通道最大数	1	重启
010001	通道0切削类型	1	重启
010002	通道1切削类型	1	重启
010009	通道0选择标志	1	重启
010010	通道1选择标志	2	重启
010017	通道0显示轴标志[1]	0x25	重启
010019	通道1显示轴标志[1]	0x18	重启
010041	是否动态显示坐标轴	0	重启
010044	半径补偿圆弧速度策略	0	保存

最大值: 2 说明: 该参数用于设置系统允许开通的最大通道数。默认设置为1, 有两个通道时设置为2。

默认值: 1

最小值: 1

\$1

↑ 保存 输入 置出 查找 自动 偏置 →

010000	Maximum number of channels	Determine number of channels to be opened in the system
010001	Cutting type of channel 0	Generally it is 1
010002	Cutting type of channel 1	When the second channel is opened, set the parameter
010017	Channel 0 display axis mark [1]	Axes 0-31 correspond to bits 0-31. If 0 is entered in binary, it means there is no axis. If 1 if entered, it means there is an axis. For axes 0, 2 and 5, bits 0, 2 and 5 are set as 1. The value calculated by the system via 2^N is 0X25 in hexadecimal.
010019	Channel 1 display axis mark [1]	When the second channel is opened, set the parameter

参数号	参数名	参数值	生效方式
010091	#500~#999为用户宏变量使能	1	重启
010092	C轴为速度模式时不刷新坐标	0	保存
010093	主程序运行前是否先运行预加载程序	0x0	保存
010096	直线极短长度过滤(mm)	0.000	复位
010097	直线极短反向轴增量过滤(mm)	0.000	复位
010098	G02/G03缺参数时是否转成G01	0	保存
010103	车削中心新功能	0x0	重启
010104	新功能调试参数	0x100	重启
010105	刀具寿命报警策略	0	保存

说明: 该参数用户设置#500~#999宏变量是否作为用户自定义宏变量使用。
 0: #500~#999不作为用户宏变量使用。
 1: #500~#999作为用户宏变量使用, 与三菱、FANUC使用一致。

最大值: 1
 默认值: 0
 最小值: 0

\$1

010091	Enable #500-#999 being user macro-variables	Only when 1 is set, these 500 variables can be displayed in the macro-variable form and can be saved automatically at the time of power failure
010104	New function debugging	0X100: When this point is valid, for example, assign 2 to #50100, if #50100 is configured as a floating point type, then the value 2 will be converted into a floating point type and assigned to variable #50100; assigned 2.3 to #50100, if #50100 is configured as an integer, then the value 2.3 is converted to an integer 2 and assigned to the variable #50100, and there is a problem of missing floating-point digits. This point is not valid. Integer values can only be assigned to integer variables, and floating-point values can only be assigned to floating-point variables.
010160	F speed display in feed per revolution	1 is set to enable this parameter when the feed per revolution is needed

The screenshot shows the 'Manual' (手动) interface of the HNC-818 system. At the top, there are buttons for '加工' (Processing), '设置' (Settings), '磨削' (Grinding), '刀补' (Tool Compensation), '诊断' (Diagnosis), and '位置' (Position). The main area displays a table of parameters:

参数号	参数名	参数值	生效方式
010170	G1007对应M代码	0	保存
010171	G1008对应M代码	0	保存
010172	G1009对应M代码	0	保存
010173	G1010对应M代码	0	保存
010174	G1011对应M代码	0	保存
010175	G1012对应M代码	0	保存
010176	G1013对应M代码	0	保存
010177	G1014对应M代码	0	保存
010178	G1015对应M代码	0	保存

说明: 用于设置对应的M代码, 通过M代码调用用户自定义宏程序

最大值: 1000
默认值: 0
最小值: 0

\$1

Buttons at the bottom: 保存 (Save), 输入口令 (Enter Password), 置出厂值 (Reset to Factory Default), 查找 (Search), 自动偏置 (Auto Offset).

010170	Corresponding M code of G1007	To call a canned cycle using M code, set corresponding M code
010171-010183 parameters are the same as 010170		
Description: Grinder 808DG opens 32 one-key G registers calling. Correspond to canned cycle in user-defined canned cycle USERDEF.CYC file. Program interval %1006---%1037, the programming format corresponds to G1006-G1037, respectively. Correspondence between G register, program interval and programming G command are as follows: G2637.0-G2637.15%1006---%1021G1006-G1021 G2619.0-G2619.15%1022---%1037 G1022-G1037		

参数号	参数名	参数值	生效方式
010329	润滑时间(单位:s)	5	保存
010330	润滑间隔时间(单位:s)	1800	保存
010331	星型启动时间(单位:s)	5	保存
010332	三角型启动时间(单位:ms)	500	保存
010333	主轴波动检测时间(ms)	0	保存
010334	用户参数[34]	0	保存
010335	用户参数[35]	0	保存
010336	用户参数[36]	0	保存
010337	用户参数[37]	0	保存

最大值: 500000 说明:

默认值: 0

最小值: -500000

\$1

保存 输入口令 置出厂值 查找 自动偏置

010329	Lubrication time of machine (unit: s)	Set based on actual situation (cooperatively used with "Lubrication" button on panel)
010330	Lubrication stop time (unit: s)	
010331	Three-phase Y-type start time (unit: ms)	5000ms by default
010332	Three-phase Delta-type start time (unit: ms)	6000ms by default, 1s switching interval time
010333	Spindle fluctuation detection time (unit: ms)	Used when there is speed arrival signal
010334	Axis X overload detection time (unit: ms)	Reflected in subprogram S19 of PLC. Set as needed
010335	Axis Z overload detection time (unit: ms)	
010336	PMC axis movement distance (us)	Set in PLC subprogram as needed

2.2.4 Channel Parameter

040001-040009	Coordinate axis number	Fill out logical axis number based on actual situation and note the correspondence between that and device interface parameters and the sequence of physical axes in the actual electrical cabinet
---------------	------------------------	--

CH1 2020-06-10 10:53:13

加工 设置 磨削 刀补 诊断 位置

参数号	参数名	参数值	生效方式
040010	主轴0轴号	5	重启
040011	主轴1轴号	6	重启
040012	主轴2轴号	-1	重启
040013	主轴3轴号	-1	重启
040014	X坐标编程名	X	保存
040015	Y坐标编程名	Y	保存
040016	Z坐标编程名	Z	保存
040017	A坐标编程名	A	保存
040018	B坐标编程名	B	保存

NC参数
机床用户参数
通道参数
通道0
通道1
通道2
通道3
坐标轴参数
误差补偿参数
设备接口参数
数据表参数

最大值: 127
默认值: -1
最小值: -1

说明: 用于配置当前通道内主轴0的轴号, 实现通道主轴与逻辑轴之间的映射。
0~127: 指定当前通道主轴的轴号。
-1: 当前通道主轴没有映射逻辑轴, 为无效轴。

\$1

保存 输入指令 置出厂值 查找 自动偏置

040010-040013	Axis number of spindle	Set based on actual need and note the correspondence between the parameter 040028 actual axis number of spindle
040014-040026	Programming name of coordinate axis	Mode name reflected in G code

参数号	参数名	参数值	生效方式
040027	主轴转速显示方式	3	保存
040028	主轴显示轴号	5,6	重启
040029	急停最大降速时间	0	重启
040030	通道的缺省进给速度(mm/min)	1000.000	保存
040031	空运行进给速度(mm/min)	5000.000	保存
040032	直径编程使能	0x1	重启
040033	UVW增量编程使能	1	保存
040034	倒角使能	0	复位
040035	角度编程使能	0	保存

NC参数
机床用户参数
通道参数
通道0
通道1
通道2
通道3
坐标轴参数
误差补偿参数
设备接口参数
数据表参数

最大值: 15
默认值: 0
最小值: 0

说明: 该参数属于置位有效参数, 用于设定通道内各主轴转速显示方式, 位0~位3分别对应主轴0~主轴3转速显示方式, 为1时显示指令转速, 为0时显示实际转速。

\$1

保存 输入指令 置出厂值 查找 自动偏置

040027	Display mode of spindle speed	<p>1. When there is an encoder feedback, 0 is set; while configuring 180U asynchronous servo and 160U feed axis as the spindle, set to 0; or when the frequency converter is used, and the encoder is externally connected, set to 0; when no encoder is used, set to 1.</p> <p>2. Pay attention to correspondence between 040010-040013 and 040028 parameters. e.g.: 040010-040013 correspond to 5, 6, 7 and 8 respectively, and spindles 2 and 3 corresponding to 040012 and 040013 have no encoder feedback. In hexadecimal, it is 1100 (the value C of 040027)</p>
040028	Display axis number of spindle	<p>Set based on 040010-040013. E.g.: 040010-040013 correspond to 5, 6, 7 and 8 respectively, set 040028 to 5, 6, 7 and 8. The sequence is the same as sequence of axes displayed on screen.</p>
040030	Default feedrate of channel (mm/min)	In G code, when the F modal doesn't exist in the previous few lines, it is the default F value of G01.
040032	Diameter programming enable	For the cylindrical grinder, enable this function.
040033	UVW incremental programming Enable	<p>Generally, it is enabled and set as 1, unless the names of U, V and W have been defined as the actual U, V and W axes. E.g. During screw grinding, thread grinding and diamond wheel dressing using a diamond pen, if U and W axes should be used at the same time, at this time U and W are actual axis names and the parameter must be set as 0. Note: G101 and G102 commands should be used for screw grinding. Example: %1234 G54 G90 G1 X100 Z100 U100 W100F1000 G101 X-1 Z-1 U-1 W-1 G102 X1 Z3 U0 W2 G91 G1 X10 Z10 F100 G101 X-1 Z-1 U-1 W-1 G102 X0 Z2 U1 W3 G91 G1 U10 W10 F100 M30</p>


	参数号	参数名	参数值	生效方式
NC参数	040037	手摇加减速时间系数	0.0000	保存
机床用户参数	040038	手摇加减速捷度时间系数	0.0000	保存
通道参数	040039	手摇加工速度系数	0.0000	保存
通道0	040040	机床结构类型	0	保存
通道1	040041	车床卧式/立式图形	0	重启
通道2	040042	圆弧降速半径	0.0000	保存
通道3	040043	圆弧降速速度	0.0000	保存
坐标轴参数	040044	通道的缺省转进给速度(mm/r)	0.0000	保存
误差补偿参数	040045	标准邻域半径	0.0000	复位
设备接口参数				
数据表参数				

最大值：100.0000
默认值：1.0000
最小值：1.0000

说明：该参数用于设置手摇移动的加速度，以对应轴参数“快移加减速时间常数”为基准值，通过“手摇加减速时间常数调整系数”对手摇加减速时间进行折算，进而改变手摇加速度，换算公式如下：手摇加工加减速时间折算值 = 快移加减速时间常数 * 手摇加减速时间常数调整系数

040037-040039	Parameters of handwheel	Set based on actual requirements. If customer needs to modify the magnifications X1, X10 and X100 of handwheel, e.g., modify to X1, X5 and X10, then users change the value of G [axis number *80+9] and assign t G (axis number) *80+9] to 1,5,10 in PLC1.
---------------	-------------------------	---

Example:



参数号	参数名	参数值	生效方式
040127	起始刀具号	1	保存
040128	刀具数目	20	保存
040130	刀具寿命管理方式	1	复位
040131	限位与保护区刀具保护功能	0	保存
040132	Z轴刀具保护与负限位距离	0.0000	保存
040133	T指令寿命管理忽略号	0	保存
040134	通道复位时, 清除同步	0	保存
040135	铣床刀具组长度补偿	0	保存
040136	铣床刀具组半径补偿	0	保存

NC参数
机床用户参数
通道参数
 通道0
 通道1
 通道2
 通道3
+ 坐标轴参数
+ 误差补偿参数
+ 设备接口参数
 数据表参数

最大值：1000
默认值：1
最小值：1

说明：该参数用于设置当前通道刀具在刀补表中的起始刀具号，与通道参数“刀具数目”配合使用。

040127	Initial tool number	Generally it is set as 1 and the T0101 programming mode is adopted
040128	Number of tools	The parameter affects the number of forms in the tool compensation table

	参数号	参数名	参数值	生效方式
NC参数	040310	倾斜轴控制使能	0	复位
机床用户参数	040311	正交轴轴号	0	复位
通道参数	040312	倾斜轴轴号	0	复位
通道0	040313	倾斜角度	0.0000	复位
通道1	040330	刀半补指令转换程序号	0	保存
通道2	040331	刀长补指令转换程序号	0	保存
通道3	040332	G5X指令转换程序号	0	保存
坐标轴参数	040333	M00转换程序号	0	保存
误差补偿参数	040340	第一组电子齿轮箱主动轴轴号	0	复位
设备接口参数				
数据表参数				

最大值：1
 默认值：0
 最小值：0

说明： 0：关闭倾斜轴功能
 1：开启倾斜轴功能

040310	Enable oblique axis control	When there is an oblique axis, the parameter is set as 1.
040311	Quadrature axis number	Z axis by default, parameter value is 2
040312	Oblique axis number	X axis by default, parameter value is 0
040313	Angle of inclination	Generally it is -30. When axis X is vertical to axis Z, taking the position of axis X as the reference, the angle value of the X position is 30 degrees when the actual X axis deviates from the orthogonality, the clockwise direction indicates the negative value, and the counterclockwise direction indicates the positive value.

2.2.5 Coordinate Axis Parameter

(1) Axis Parameter on Control System

Logical axes 0,1--N. According to actual situation, select logical axis number corresponding to axis number set in machine user parameter and channel parameter.

Here descriptions are given with X axis and axis 0 as an example.



100000	Display axis name	The parameter determines axis name displayed in the system interface
--------	-------------------	--

100001	Axis type	<p>Description:</p> <p>0: Not configured, default value. 1: Linear axis.</p> <p>2: Swing axis, the coordinate value of displayed angle is not limited.</p> <p>3: Rotary axis, the coordinate value of displayed angle is within the designated range and it will be displayed modulo when the actual coordinates exceeds the set value.</p> <p>9: When traverse axis is used as spindle, the drive is the feed axis drive.</p> <p>10: Spindle.</p> <p>Set based on the actually-used drive and the function requirements.</p> <p>It should be specially noted that several parameters in device interface parameters associated with this parameter, as shown in the image below:</p>
--------	-----------	---

参数号	参数名	参数值	生效方式
507000	设备名称	AX	固化
507002	设备类型	1002	固化
507003	同组设备序号	0	固化
507004	设备ID	0x0	固化
507010	工作模式	1	重启
507011	逻辑轴号	0	重启
507012	编码器反馈取反标志	0	重启
507013	指令脉冲输出类型	0	重启
507014	反馈位置循环使能	0	重启

最大值： / 说明：
 默认值： /
 最小值： /

507010	Working mode	0: No position command output 1: Position incremental mode 2: Position absolute mode 3: Speed mode 4: Current mode (torque mode) Generally working mode of feed axis is set as 1 and that of spindle is set as 3
507014	Feedback position loop enable	0: Feedback position does not adopt cycle counting mode 1: Feedback position adopts cycle counting mode 2: This mode is adopted when feed axis servo is switched to spindle The parameter should be set as 0 for linear feed axis and swing axis and 1 for rotary axis and spindle

参数号	参数名	参数值	生效方式
100004	电子齿轮比分子[位移](um)	4000	重启
100005	电子齿轮比分母[脉冲]	131072	重启
100006	正软极限坐标(mm)	2000.0000	复位
100007	负软极限坐标(mm)	-2000.0000	复位
100008	第2正软极限坐标(mm)	0.0000	复位
100009	第2负软极限坐标(mm)	0.0000	复位
100010	回参考点模式	0	保存
100011	回参考点方向	1	复位
100012	编码器反馈偏置量(mm)	0.0000	重启

最大值： 99999999 说明： 对于直线轴而言，本参数是用来设置电机每转一圈机床移动的距离。
 对于旋转轴而言，本参数是用来设置电机每转一圈机床移动的角度。
 默认值： 1
 最小值： -99999999

100004	Numerator of electronic gear ratio [displacement] (um)	① Linear axis: Motor connects directly to screw rod. 1:1 transmission ratio, 100004 is the thread pitch of screw rod
--------	--	--

100005	Denominator of electronic gear ratio [pulse]	<p>in the unit mm; 100005 is the number of pulses per revolution of motor and common type of Huada motor is 131072. If transmission ratio between motor and screw rod is not 1:1, it is necessary to multiply the actual mechanical transmission ratio on the basis of the numerical ratio in the case of the above direct connection.</p> <p>② Speed axis: When mechanical transmission ratio is 1:1, 100004 value is 360000 (s), 100005 is the number of pulses per revolution of motor and common type of HCNC asynchronous servomotor is 4096. If transmission ratio is not 1:1, it is necessary to multiply the actual mechanical transmission ratio.</p> <p>③ Switching feed axis to spindle: Transmission ratio is calculated using the same method in ②.</p> <p>④ Swing axis, rotary axis: Transmission ratio is calculated using the same method in ②.</p>
100006	Positive software limit coordinate	For software limit, it should be noted that after "Enable diameter programming", software limit of diameter axis is 1/2 of the displayed coordinate value
100007	Negative software limit coordinate	

参数号	参数名	参数值	生效方式
100010	回参考点模式	0	保存
100011	回参考点方向	1	复位
100012	编码器反馈偏置量(mm)	0.0000	重启
100013	回参考点后的偏移量(mm)	0.0000	复位
100014	回参考点Z脉冲屏蔽角度(度)	0.0000	保存
100015	回参考点高速(mm/min)	3000.0000	复位
100016	回参考点低速(mm/min)	500.0000	复位
100017	参考点坐标值(mm)	0.0000	复位
100018	距离码参考点间距(mm)	20.0000	复位

说明： HNC-8数控系统回参考点模式分为以下几种：
 0：绝对编码
 2：+-
 3：--+
 4：距离码回零方式1
 5：距离码回零方式2

最大值：5
 默认值：0
 最小值：0

10010-100016	Parameters of reference point return	<p>Set based on actual situation; it should be noted that for 100012 encoder feedback offset amount, enter the corresponding axis number in "Auto offset" under "Set" module. Press the emergency stop button and reset to validate the setting.</p> <p>As shown below, set zero point of axis.</p>
--------------	--------------------------------------	---

Axis zero setting



参数号	参数名	参数值	生效方式
100032	慢速点动速度(mm/min)	3000.0000	复位
100033	快速点动速度(mm/min)	5000.0000	复位
100034	最大快移速度(mm/min)	8000.0000	复位
100035	最高加工速度(mm/min)	6000.0000	保存
100036	快移加减速时间常数(ms)	16.0000	复位
100037	快移加减速捷度时间常数(ms)	128.0000	复位
100038	加工加减速时间常数(ms)	16.0000	复位
100039	加工加减速捷度时间常数(ms)	128.0000	复位
100043	手摇脉冲分辨率(um)	1.0000	复位

最大值：360000.0000
默认值：2000.0000
最小值：0.0000

说明：该参数用于设定手动模式（JOG）下轴的慢速点动速度。当在手动模式（JOG）下点动轴时，轴的移动速度还受进给修调的影响。旋转轴受转动半径影响。

10032-100039	Axis speed, acceleration/deceleration adjustment	Calculate according to actual thread pitch, transmission ratio and maximum motor speed. It should be stressed that while switching spindle to feed axis, the speed should be set as the maximum allowable parameter value; otherwise, rotation speed S cannot increase.
--------------	--	---

参数号	参数名	参数值	生效方式
100043	手摇脉冲分辨率(um)	1.0000	复位
100045	手摇缓冲周期数(ms)	100	保存
100047	手摇最高速度	6000.0000	保存
100048	超速报警系数	0.0000	保存
100049	螺纹修复时的1m/min跟踪误差(mm)	0.0000	保存
100050	缺省S转速值(rad/min)	10.0000	重启
100052	主轴转速允许波动率	0.0000	复位
100054	螺纹加工主轴转速允许波动率	0.0000	保存
100055	进给主轴定向角度(度)	0.0000	保存

最大值：1000.0000
默认值：1.0000
最小值：0.0010

说明：本参数设置当手摇倍率×1时摇动手摇一格发出一个脉冲轴所走的距离。parm01001“工位机机床类型”设为1（车床）并且Parm040032“直半径编程使能”也为1时，X轴所对应的手摇脉冲分辨率为0.5。

10043-100047	Parameters of handwheel	Refer to the relevant explanations in the channel parameters
--------------	-------------------------	--

参数号	参数名	参数值	生效方式
100050	缺省S转速值(rad/min)	10.0000	重启
100052	主轴转速允许波动率	0.0000	复位
100054	螺纹加工主轴转速允许波动率	0.0000	保存
100055	进给主轴定向角度(度)	0.0000	保存
100056	进给主轴零速允差(脉冲)	0	保存
100057	外部指令最大周期叠加量	0.0000	保存
100058	负载由外部导入	0	保存
100060	定位允差(mm)	0.0000	保存
100061	1m/min的最大跟随误差(mm)	10.0000	复位

最大值：100000.0000
默认值：100.0000
最小值：0.0000

说明：当指定主轴正反转M03或M04的时候，如果没有指定转速S，则使用由本参数设定的缺省S转速值。如M3指令后面跟了主轴转速，那么下次再写M3而不跟主轴转速则取上次主轴转速，缺省S转速值只在没有指定过主轴转速时生效。

100050	Default S speed (rad/min)	Default manual speed, set based on actual need
100055	Feed spindle orientation angle (degree)	Parameters of orientation and zero speed when the feed axis is used as the spindle. Set based on field commissioning situation.
100056	Tolerance of feed spindle zero speed (pulse)	

参数号	参数名	参数值	生效方式
100060	定位允差(mm)	0.0000	保存
100061	1m/min的最大跟随误差(mm)	10.0000	复位
100062	柔性同步自动调整使能	0	复位
100067	轴每转脉冲数(脉冲)	131072	复位
100068	丝杠导程(mm)	4.0000	保存
100073	旋转轴速度显示系数	1.0000	保存
100077	分度/定位轴类型	0	保存
100078	分度/定位轴起始值	0.0000	保存
100079	分度/定位轴间距	0.0000	保存

最大值：1000.0000
默认值：0.1000
最小值：0.0000

说明：该参数用于设定坐标轴快移定位（G00）所允许的准停误差。
0：当前轴无定位允差限制
大于0：当达到Parm 010166 “准停检测最大时间”后当前轴机床坐标仍然超出定位允差设定值时数控系统将报警。

100060	Positioning tolerance (mm)	Set based on actual situation. When the value is 0, the system does not detect positioning tolerance.
100061	Maximum tracking error of 1m/min (mm)	Fill out according to actual situation. When the value is 0, the system does not detect following tolerance.
100062	Pulse count per revolution of axis (pulse)	Pulse count per revolution of motor when mechanical transmission ratio is 1:1. The parameter is often set to the same value as the parameter Number of Feedback Position Loop Pulses in the device interface parameter. If numerator and denominator of electronic gear ratio in the axis parameters have no reduction of a fraction, it also has the same value as "Denominator of Electronic Gear Ratio" in the axis parameters.
100068	Screw rod lead (mm)	Set based on actual thread pitch, take effect while shifting gear stages
100073	Displayed coefficient of	When the axis type is rotary axis, modify the

	rotary axis speed	parameter. Conversion between degree/min and rev/min
--	-------------------	--

(2) Axis Parameter on Servo

Common commissioning parameters

P0	Position proportional gain	Set based on actual situation
P2	Speed proportional gain	
P4	Speed feedback filter coefficient	
P24	Number of motor pole pairs	
P25	Rotary axis speed display coefficient	
P26	Encoder zero offset	
P27	Current proportional gain	
P43	Specification of 160/180UD drive. For 180US drive, corresponding parameter is P59	

2.2.6 Device Interface Parameter

CH1 2020-06-10 11:16:54

手动 加工 设置 磨削 刀补 诊断 位置

参数号	参数名	参数值	生效方式
504000	设备名称	SP	固化
504002	设备类型	1001	固化
504003	同组设备序号	0	固化
504004	设备ID	0x0	固化
504010	工作模式	3	重启
504011	逻辑轴号	6	重启
504012	编码器反馈取反标志	0	重启
504013	主轴DA输出类型	0	重启
504014	主轴DA输出零漂调整量(mv)	0	重启

最大值: / 说明:
默认值: /
最小值: /

\$1

↑ 保存 输入口令 置出厂值 查找 自动偏置 →

Analog spindle of device 4		
504010	Working mode	Generally it is set as 3, speed working mode.
504011	Logical axis number	Refer to the axis number corresponding to spindle set in the channel parameters.
504012	Inverse encoder feedback mark	If the mark of feedback S is not the same as the actual situation, modify the parameter
504013	Spindle DA output type	Select 0-10V or -10V-10V based on actual situation
504014	Spindle DA output zero drift adjustment amount (mv)	The measured DA output value when the spindle is at M3S0, in the nit mv
504015	Pulse count of feedback position loop	Generally it is 4096, and it should be set according to actual situation
504016	Spindle encoder feedback device number	Set based on the device number of control panel feedback interface
504017	Spindle DA output device number	Device number occupied by electrical IO
504018	Spindle encoder feedback interface number	Calculate the number of shifted groups (16 bits as a group) according to 504016 and electrical IN signal.
504019	Axis DA output port number	Calculate the number of shifted groups (16 bits as a group) according to 504017 and electrical OUT signal.

MCP unit of 808DG system occupies 2 devices: device 5 and device 6



Device 5

505010	MCP type	7
505012	Initial group number of input point	480
505013	Number of input point groups	10
505014	Initial group number of output point	480
505015	Number of output point groups	10
505016	Inverse handwheel direction mark	If the moving direction of the handwheel axis is opposite to the actual direction, modify this parameter
505018	Band switch encoding type	Band switch type selection

参数号	参数名	参数值	生效方式
506000	设备名称	MCP_NET	固化
506002	设备类型	2008	固化
506003	同组设备序号	0	固化
506004	设备ID	0x0	固化
506010	MCP类型	7	重启
506011	保留	0	重启
506012	输入点起始组号	490	重启
506013	输入点组数	10	重启
506014	输出点起始组号	490	重启

最大值： / 说明：
 默认值： /
 最小值： /

参数号	参数名	参数值	生效方式
506010	MCP类型	7	重启
506011	保留	0	重启
506012	输入点起始组号	490	重启
506013	输入点组数	10	重启
506014	输出点起始组号	490	重启
506015	输出点组数	10	重启
506016	手摇方向取反标志	0	重启
506018	波段开关编码类型	1	重启
506019	追加模拟量主轴数	0	重启

最大值： 128 说明： 该参数用于标识总线控制面板输出信号的组数。
 默认值： 30 注 意
 最小值： 0 总线控制面板输出点组数默认为30组，修改该参数不会改变控制面板实际输出点组数。

Device 6

506010	MCP type	7
506012	Initial group number of input point	490
506013	Number of input point groups	10
506014	Initial group number of output point	490
506015	Number of output point groups	10
506019	Number of additional analog spindles	When more than one analog spindles are needed, modify this parameter. If two groups of analog spindles are needed, number of additional analog spindles is 1




Device parameters corresponding to axes should be set according to axis configuration in channel parameters.

507010	Working mode	Set based on actual situation
507011	Logical axis number	Set based on actual situation
507012	Inverse encoder feedback mark	When the displayed rotate speed of the spindle is opposite to the actual rotation direction, the parameter can be set as 1
507014	Feedback position loop mode	Pay attention to the value when the feed axis is switched to the spindle
507015	Pulse count of feedback position loop	Generally it is the pulse count of axis per revolution, note whether mechanical transmission ratio is 1:1 and refer to relevant 2 parameters in axis parameters
507016	Encoder type	Generally the absolute value is 3

2.3 PLC Commissioning


2.3.1 HNC-8 PLC Structure

HNC-8 ladder diagram PLC adopts cyclic scanning mode. In the beginning of program execution, PLC will be initialized once when it is powered on or reloaded. Then all inputted states are transmitted to the input map register. Afterwards, call user programs PLC1 and PLC2 in sequence. When a scanning cycle is completed, all results will be transmitted to the output map register to control actual output of PLC, and so on.



2.3.2 Working Principle of PLC Interface Signal

PLC interface signal is responsible for information exchange between PLC and NC.



- F register is a state flag register used to input CNC input signal to PLC control module from CNC.
- G register is a control flag register used to output CNC output signal to CNC from PLC control module and the signals are processed by CNC.
- B register is a data register (saving data after power off), and the value of the register still remains at the state before power-off after power-off. The data register can also be used as PLC parameter and users can define usage of each parameter.

2.3.3 PLC Specification

Specification	HNC8
Programming language	Ladder, STL
The first-level program execution cycle	1ms
Program capacity Ladder diagram Statement list Symbol name	5000 lines 10000 lines 1000 pcs.
Command Basic command, function command	
Single-byte internal relay (R) Dual-byte internal register (W) Four-byte internal register (D) Timer (T) Counter (C) Subprogram (S) Mark number (L) User-defined parameter (P) Single-byte internal register (I) Single-byte internal register (Q) Holding-type storage area Four-byte register (B) Holding relay (K)	2048 bytes (R0-R2047) 512 bytes (W0-W255) 1024 bytes (D0-D255) 512 (T0-T511) 512 (C0-C511) 253 (S0-S252) 10000(L0-L9999) 700(P0-P699) 128 bytes (I0-I127) 128 bytes (Q0-Q127) 6888 bytes (B0-B1721) 128 bytes (K0-K15)
I/O module (X) (Y)	X0-X511 Y0-Y511

2.3.4 PLC Switch File and P Parameter

(1) PLC switch

Set → PLC switch

索引号	名称	索引号	名称
1	径向量仪1到位信号有无	17	
2	径向量仪2到位信号有无	18	
3	端面量仪到位信号有无	19	
4	速度轴选择D/A(0:变频;1:伺服)	20	
5	速度轴零速信号有无	21	
6	速度轴速度到达信号有无	22	
7	是否星三角	23	
8	轴5是否是进给轴做主轴	24	
9	Z轴是否是PMC轴	25	
10	调试屏蔽急停	26	
11		27	
12		28	
13		29	
14		30	
15		31	
16		32	
\$1			

This part is all mapped to PLC ladder diagram and should be opened according to actual needs.

Correspond to P196 point. Parameters 1-32 correspond to P196.0-P196.31. For example, parameter 10 is the P196.9. This part is used for auxiliary debugging including shielding and emergency stop, etc.

(2) P parameter

索引	参数号	参数名	参数值
1	010329	润滑时间(单位:s)	5
2	010330	润滑间隔时间(单位:s)	1800
3	010331	星型启动时间(单位:s)	5
4	010332	三角型启动时间(单位:ms)	500
5	010333	主轴波动检测时间(ms)	0
6	010334	用户参数[34]	0
7	010335	用户参数[35]	0
8	010336	用户参数[36]	0
9	010337	用户参数[37]	0
10	010338	用户参数[38]	0
11	010339	用户参数[39]	0
12	010340	主轴1最高转速	1000
13	010345	主轴2最高转速	0

Note: Corresponding P parameters can also be modified here.

2.3.5 Common PLC Module

(1) G31 module

Specify the axis moving after G31 command just like specifying linear interpolation in G01. If an external skip signal is inputted when this command is executed, the command execution is interrupted and the next program block is executed.


Format

G31 L_IP_; Figure after L is the contact point number, which is consistent with the contact number in PLC

G31: Non-modal G code

(2) USERIN

As shown above, user-defined input. Used to judge whether signal arrives, that is, the value of #1190 is reflected by G code.



(3) VARGET and VARSET modules

- Variable type


Variable type <Address 1>	Variable offset number <Address 2>
0: User variable	0 to 4999 correspond to #50000 to #54999
1: Extended user variable	0 to 499 correspond to #500 to #999
2: 32-bit integer system variable	0 to 9999 correspond #40000 to #49999
3: 64-bit integer system variable	0 to 4999 correspond to #40000, #40002...#49998
4: Floating point system variable	0 to 4999 correspond to #40000, #40002...#49998
5: 32-bit integer channel variable	0 to 7999 correspond to #0 to #7999
6: Floating point channel variable	0 to 3999 correspond to #0, #2...#7998
7: 32-bit integer axis variable	0 to 9999 correspond to #60000 to #69999
8: 64-bit integer axis variable	0 to 4999 correspond to #60000, #60002...#69998
9: Tool variable	0 to 19999 correspond to #70000 to #99999

Note:

- ① Channel variables, each channel occupies 2000 variables. That is, #0 to #1999 are channel 0 variables, #2000 to #3999 are channel 1 variables, #4000 to #5999 are channel 2 variables, and #6000 to #7999 are channel 3 variables.
- ② Axis variables, each axis occupies 100 variables, that is, #60000 to #60100 are axis 0 variables, and so on.
- ③ Tool variables, each tool occupies 200 variables, that is, #70000 to #70200 are the variables of the No. 1 tool, and so on.

- VARGET (read system variable value)

Format



Parameter	Storage area	Description
<Address 1>	Constant	Variable type, ranges from 0 to 9.
<Address 2>	Constant, X, Y, F, G, R, W, D, P, B	The offset of the variable. The value increased of the starting variable number corresponding to the variable type selected in <Address 1>.
<Address 3>	Constant	The exponent of 10. It is used to enlarge the value of the variable.
<Address 4>	Y, G, R, W, D, B	The register address of the value that needs to be assigned to the system variable.

①Function description

The PLC reads various variable values of the system and assigns them to registers.

②Parameter description

Parameter 1: Variable value type;

Parameter 2: The offset number of the read variable address (it can be a constant or the value in a register);

Parameter 3: Floating-point variable increases the multiples of 10 (that is, 10 to the power of N, N is the value of the parameter);

Parameter 4: The address where the value of the variable to be read is stored

③Usage instructions

The number of the macro variable being read = the starting variable number corresponding to <address 1> + the offset number of <address 2>.

The assigned register is the register filled in <Address 4>.

The assigned value is the value of the macro variable*10 to the power of N (N is the value in <address 3>)

Example



Increase the value of floating-point user macro variable #51242 by 100 times (10 to the power of 2) and assign it to register D30.

The first parameter: 0 represents the data type. This place indicates that the variable in the interval #50000-#54999 is selected.

The second parameter: 1242 represents the #51242 variable

The third parameter: 2 indicates square of 10, which is 100.

The fourth parameter: D30 means: the value in #51242 is taken out, and multiplied by 100 (the third parameter), and then stored in the register D30.


Note: ①If the data type of #51242 is INT, and 0,1,2.... is filled in for the third parameter according to actual needs, that means, 1 times, 10 times, 100 times, and 10 to the Nth power.

②If the data type of #51242 is FLOAT, and it is a four-digit decimal, then the third parameter is 4 or a value greater than 4 according to actual needs, that is 10000 times. The value of #51242 is multiplied by 10000, which is converted from a decimal to an integer, and stored in the D register.

③ HCNC control system PLC cannot directly process numerical values with decimals, but can only process integer values. Therefore, as mentioned in item ②, if #51242 is a decimal number, it must be converted into an integer value to participate in the PLC calculation.

● VARSET (set various of variable values of system)

Format



Parameter	Storage area	Description
<Address 1>	Constant	Variable type, can be 0, 1, 2, 9
<Address 2>	Constant, X, Y, F, G, R, W, D, P, B	The offset of the variable. The value increased of the starting variable number corresponding to the variable type selected in <Address 1>.
<Address 3>	Constant	The exponent of 10. It is used to reduce the value of the variable.
<Address 4>	Y, G, R, W, D, B	The register address of the value that needs to be assigned to the system variable.

①Function description

Set the variable value of the system through the register in the PLC.

②Parameter description

Parameter 1: Variable value type;

Parameter 2: The offset number of the variable address that needs to be set (it can be a constant or a value in a register);

Parameter 3: The value is reduced by the multiples of 10 (that is, the Nth power of 10, N is the value of this parameter);

Parameter 4: The register address of the value that needs to be assigned to the system variable

③Usage instructions

The assigned macro variable number = the starting variable number corresponding to <address 1> + the offset number of <address 2>.

The register used for assignment is the register filled in <address 4>.

The assigned value = the value of the macro variable / 10 to the power of N (N is the value in <address 3>)

Example



The first parameter: 0 represents the data type. This place indicates that the variable in the interval #50000-#54999 is selected.

The second parameter: 1425 represents #50000 offset 1425, which is the variable #51425

The third parameter: 0 represents 10 to the 0 power, which is 1.

The fourth parameter: Divide the value of D31 by the Nth power of 10 (N is the value of the third parameter), and the result is assigned to the macro variable #51425 for the numerical calculation of the macro variable in the G code.

Note: ①The third parameter is the value 0 for the current example.

Divide the value of D31 by the Nth power of 10 (N is the value of the third parameter), and the result is assigned to the macro variable. If #51425 in the G code is of type INT, use it directly in the G code; if #51425 in the G code is FLOAT type, use it directly in the G code, and divide by the corresponding value according to the actual situation, such as 10,100,1000,1000, and then perform the calculation with it.

2.3.6 PLC Point

Input point:

X0.0	Wheel alarm	X2.0	Radial 1 measuring instrument advances to the right position
X0.1	Oil pump alarm	X2.1	Radial 1 measuring instrument retracts to the right position

X0.2	Water pump alarm	X2.2	Radial 2 measuring instrument advances to the right position
X0.3		X2.3	Radial 2 measuring instrument retracts to the right position
X0.4	PWM spindle alarm	X2.4	The end face measuring instrument advances to the right position
X0.5		X2.5	The end face measuring instrument retracts to the right position
X0.6	Air conditioner alarm	X2.6	Air switch
X0.7		X2.7	External emergency stop
X1.0	Radial measuring instrument P1	X3.0	
X1.1	Radial measuring instrument P2	X3.1	
X1.2	Radial measuring instrument P3	X3.2	
X1.3	Radial measuring instrument P4	X3.3	The tailstock advances to the right position
X1.4	End face measuring instrument	X3.4	The tailstock retracts to the right position
X1.5		X3.5	Zero speed signal
X1.6		X3.6	Speed arrival signal
X1.7		X3.7	

Output point:

Y0.0	Headstock rotation	Y2.0	
Y0.1	Wheel rotation	Y2.1	
Y0.2	Three-phase Y type start	Y2.2	
Y0.3	Three-phase Delta type start	Y2.3	
Y0.4	Cooling	Y2.4	
Y0.5	Oil pump	Y2.5	
Y0.6	Lubrication	Y2.6	
Y0.7	Work light	Y2.7	
Y1.0	Outer diameter measuring instrument stretching and retract	Y3.0	

Y1.1	End face measuring instrument stretching and retract	Y3.1	
Y1.2		Y3.2	
Y1.3		Y3.3	
Y1.4		Y3.4	
Y1.5		Y3.5	
Y1.6		Y3.6	
Y1.7		Y3.7	

2.3.7 M Code

M code	Description	M code	Description	M code	Description
M3	Headstock ON	M25	Servo sampling ON	M52	Thread OFF
M5	Headstock OFF	M26	Servo sampling OFF	M90	User input
M7	Cooling ON	M30	Program end	M91	User output
M9	Cooling OFF	M33	Wheel ON	M92	Manual intervention ON
M12	Radial 1 measuring instrument 1 extends	M35	Wheel OFF	M93	Manual intervention OFF
M13	Radial 1 measuring instrument retracts	M44	Chuck clamping	M150	Cancel measuring instrument signal
M14	Radial 2 measuring instrument extends	M45	Chuck release	M151	Radial 1 measuring instrument P1
M15	Radial 2 measuring instrument retracts	M46	Oil pump ON	M152	Radial 1 measuring instrument P2
M16	End face measuring instrument stretching	M47	Oil pump OFF	M153	Radial 1 measuring instrument P3
M17	End face measuring instrument retract	M48	Tailstock stretching	M154	Radial 1 measuring instrument P4
M19	Orientation ON	M49	Tailstock retract	M161	End face measuring instrument P1
M20	Orientation OFF	M51	Thread ON	M162	End face measuring instrument P2

2.4 Common G Code Command

2.4.1 G10 Command

G90(G91)G10 L2PpIP

Parameter	Meaning
Pp	Specify workpiece origin offset of relative workpiece coordinate systems 1-6: <ul style="list-style-type: none"> ➤ 1 corresponds to G54 workpiece coordinate system ➤ 2 corresponds to G55 workpiece coordinate system ➤ 3 corresponds to G56 workpiece coordinate system ➤ 4 corresponds to G57 workpiece coordinate system ➤ 5 corresponds to G58 workpiece coordinate system ➤ 6 corresponds to G59 workpiece coordinate system
IP	For absolute programming, it is the workpiece origin offset of each axis For incremental programming, accumulated to the original workpiece origin offset of each axis

G90(G91)G10 L14 Pp X_ Z_ ; format of cumulative wear value: 10L14U_ W_

Parameter	Meaning
Pp	Tool offset number
X	Tool compensation data X
Z	Tool compensation data Z

2.4.2 Stop Read-ahead

(1) G08

If the command is encountered during program execution, the system stops the interpretation of the subsequent lines and continues to interpret and run only after the previous interpreted commands are executed. The command is frequently used in real-time coordinate reading and status determination.

(2) G31 L-2 Kx.

Stop read-ahead of corresponding axes. The value of X after K is 2^N and N is the axis number. It is applicable to reading coordinate variables after skip.

2.4.3 Other Codes

G108, G109 C axis mode switching

G101, G102 Release and acquisition of axis

G110 Custom alarm usage

M98, G65 When users write the macro program by themselves, they can choose to use it according to the actual situation

2.5 New Functions in Version 2.40.01

2.5.1 Technology Encryption Function

After the canned cycle file TURNING.CYC and the custom cycle file USERDEF.CYC are encrypted, the TURNING.CYC and USERDEF.CYC programs on the system are invisible and cannot be edited. After TURNING.CYC and USERDEF.CYC files are opened, they show garbled characters, and the technology program can only be seen after decryption.

Canned cycle files TUINING.CYC and USERDEF.CYC cannot be loaded and exported through data management.

The program written by users can also be encrypted to protect the users' technology.



After encryption, the program is invisible and cannot be edited.



Encryption program is running



2.5.2 System Display Manual

As shown below in the figure, press Grind → User file



Click the submenu Open File to open corresponding manual to view the manual. The up and down direction keys can be used to turn pages and locate pages.




The WORD manual written by users can be upgraded to the system, and the manual can be viewed on the system.

2.5.3 Backup and Restore of Grinding Data

Press Set → Data manage to select Grinding Value DAT to back up and restore workpiece grinding data. The data can be backed up to U Disk or User Disk. Users do not need to fill in the grinding process variable value again when replacing the workpiece, but only needs to import and export the grinding process file, which is

convenient for the user to replace the workpiece



The menu Technology Package menu is for the technology data backup, and the menu Process Restore is for the technology data restoration.



E.g:

For workpiece 1, the technology grinding data is backed up as GONGJIAN1.DAT file through the Technology Package function.

For workpiece 2, the technology grinding data is backed up as GONGJIAN2.DAT file through the Technology Package function.

CH1 2020-09-22 17:56:26

手动 程序 设置 磨削 刀补 诊断 位置

	机床实际	工件实际	剩余进给
X	49.995	49.995	0.000
Z	-33.309	-33.309	0.000
C	116.551	116.551	0.000

公共参数 轴台选项 轴台1

径向量仪是否使用	0
对应几号量仪	1
径向量仪校正X坐标	0
磨削方式	2
X向安全位置	100.000
Z向安全位置	0.000
X向快趋位置	60.000
Z向快趋位置	0.000
靠近毛坯速度	2.000
毛坯直径	59.800
量仪伸出前磨削量	0.100

参数说明:
单位: mm

\$1 Workpiece 1 grinding data GONGJIAN1.DAT

公共参数 切入磨 纵磨 多次切入

CH1 2020-09-22 17:57:19

手动 程序 设置 磨削 刀补 诊断 位置

系统盘 磨削值DAT ../data


名称	大小	修改时间
..		
GRINDDATA		2020-08-31 03:11:20
grinddata		2020-08-28 05:50:01
332.DAT	87KB	2020-08-20 15:59:14
10.DAT	87KB	2020-08-20 15:57:53

U盘 磨削值DAT /g

名称	大小	修改时间
..		
0g2637		2020-09-11 15:15:44
0820mi		2020-08-20 14:17:58
zairushuomingshu		2020-08-19 11:08:06
1.0jiami		2020-07-20 10:16:36

\$1 磨削工艺所有变量GONGJIAN1.DAT备份, 成功!

载入 备份 删除 重命名 工艺打包 工艺还原 窗口切换



Import the technology grinding data of corresponding workpiece through Technology Restore





2.5.4 Insert Cycle

Press PROG → Edit to insert cycle.



The Insert Cycle function includes common grinding canned cycles. There is a corresponding schematic diagram on the right side of each parameter to facilitate users to understand and fill in the grinding parameter values. After filling in the parameters, press NC Output to output the canned cycle program to the program editing cursor. The Insert Cycle function is convenient for users to write canned cycle programs, users do not need to memorize the meaning of each parameter, just fill in the parameters according to the schematic diagram.





2.5.5 Grinding Card Interface Refreshing

Different technology parameters correspond to different schematic diagrams, which is convenient for users to understand and fill in the technology parameters.





2.5.6 Oblique Axis

(1) During tool setting, the workpiece coordinates are updated in real time



(2) Tool setting can be performed to oblique axis like straight axis. Users can enter pre-grinding diameter for X-direction tool setting, then retract on X axis, and enter pre-grinding length for Z-direction tool setting.

(3) Oblique axis record coordinate tool setting function

Calculate the X-axis and Z-axis offset according to the recorded coordinates.

刀号		X	Z	T
1	偏置	42.544	-34.531	工件磨削——T0101
	磨损	0.000	0.000	
2	偏置	-103.179	-94.725	砂轮外圆修整——T0102
	磨损	0.000	0.000	
3	偏置	0.000	-9.692	工件端面测量——T0103
	磨损	0.000	0.000	
4	偏置	0.000	0.000	砂轮端面修整——T0104
	磨损	0.000	0.000	
5	偏置	0.000	0.000	保留待用——T0105
	磨损	0.000	0.000	

	机床实际	相对实际	工件实际	记录坐标
X	225.062	140.569	158.065	100.279
Z	-135.335	-123.068	-55.175	-48.965
C	0.000	0.000	0.000	

2.5.7 G153/G154 Axis Oscillation Function

Command of turning on axis oscillation: G153 IP_P_

Command of turning off axis oscillation: G154 IP0

Note: IP is the axis that needs to turn on the oscillation function, such as X, Z; IP is followed by the oscillation distance, positive and negative directions; P_ is the oscillation axis speed.

For example,

```
%123
T0101
G90 G1 Z0 F1000
G153 Z50 P2000 ; Z-axis oscillation is turned on, Z axis oscillates between 0 and 50.
G4X5
G154 Z0 ; Oscillation is turned off.
M30
```

System parameters related to axis oscillation:

10X153 Whether stop axis oscillation immediately

10X154 Oscillation speed is controlled by override

NC CH1 2020-09-21 14:24:52

手动 程序 设置 磨削 刀补 诊断 位置

参数号	参数名	参数值	生效方式
100147	随动位置上限	0.000	重启
100148	蛙跳切换到随动的高度	0.000	重启
100149	随动电压模式	0	重启
100150	标定的间距	0.000	重启
100151	碰板电压	0.000	重启
100153	震荡是否立即停止	0	复位
100154	震荡速度受修调控制	1	复位
100155	S指令需要响应	0	复位
100156	主轴输出模拟量	0	复位

NC参数
机床用户参数
通道参数
通道0
通道1
通道2
通道3
坐标轴参数
逻辑轴0
逻辑轴1
逻辑轴2
逻辑轴3

最大值: 1
默认值: 0
最小值: 0

说明: 此参数为轴震荡参数。
0: 震荡到起点位置停。
1: 震荡立即停。

\$1

保存 输入 置出 查找 自动

NC CH1 2020-09-21 14:32:24

手动 程序 设置 磨削 刀补 诊断 位置

参数号	参数名	参数值	生效方式
100147	随动位置上限	0.000	重启
100148	蛙跳切换到随动的高度	0.000	重启
100149	随动电压模式	0	重启
100150	标定的间距	0.000	重启
100151	碰板电压	0.000	重启
100153	震荡是否立即停止	0	复位
100154	震荡速度受修调控制	1	复位
100155	S指令需要响应	0	复位
100156	主轴输出模拟量	0	复位

NC参数
机床用户参数
通道参数
通道0
通道1
通道2
通道3
坐标轴参数
逻辑轴0
逻辑轴1
逻辑轴2
逻辑轴3

最大值: 1
默认值: 0
最小值: 0

说明: 此参数为轴震荡参数。
0: 震荡速度不受进给修调控制。
1: 震荡速度受进给修调控制

\$1

保存 输入 置出 查找 自动

2.5.8 Workpiece Coordinate System Zero Translation Commands G155, G156

Format: G155 U_ W_ ; Workpiece coordinate system zero translation

G156; Cancel translation

Or G155 U_ W_ P_ ; Workpiece coordinate system zero translation of specified tool number

G156 P_n; Cancel translation of specified tool

Description: U_xW_z is the translation increment corresponding to X axis and Z axis. P_n is the tool number, for example, P1 is T0101, P2 is T0102.

G155 U_xW_z can only perform the incremental translation of current zero of the workpiece coordinate system established by T command, and the translation value only takes effect when encountering T command.

G156 cancels the translation of all workpiece coordinate systems.

G155 U_xW_zP_n can only perform the incremental translation of current zero of the workpiece coordinate system established by T command for specified tool, and the translation value only takes effect when encountering T command.

G156 P_n cancels the translation of the workpiece coordinate system established by the T command for the specified tool number.

For example,

%1

G156 P1; Cancel the translation of tool 1

T0103; Tool setting with end face measuring instrument

G01 X50 F2000

G01 Z-10

M151

G31 G01 L1 W-10 F200

W2

G31 G01 L1 W-5 F10

#54005=#1022-#1032; Take the error value of each detection by the end face measuring instrument

G155 P1 W[#54005]; Translate the error value detected by the end measuring instrument each time to the grinding tool T0101

G01 Z-10

T0101; Grinding tool

G01 X50 F2000

Z0

.....

M30

3 Grinding Technology Introduction

3.1 Canned Cycle

3.1.1 Plunge Grinding

Single-times plunge grinding: G77 X (U) _ F _ P _ A _ O _

X (U) — X is the target coordinate value. G90 is the absolute programming mode, and G91 is the incremental programming mode. U is a value relative to start point of grinding, and \pm represents directions. (Diameter programming is by default. If it needs to be modified, modify diameter/radius mode in system parameters)

F — Feedrate of grinding wheel (X direction).

P — Measuring instrument signal. If P value is set, it means that the measuring instrument is used; otherwise, it means that measuring instrument is not used. P1 represents the rough grinding in-position signal. P2 represents the semi-fine grinding in-position signal. P3 represents the fine grinding in-position signal. P4 represents the dimension signal.


A — A: When no value is specified, establish workpiece coordinate system using T0101. When the value is 1, establish workpiece coordinate system using G54 mode.

O — Whether the coordinate system is corrected after the measuring instrument dimension arrival signal is triggered. When no value is specified, coordinates are not corrected after the dimension is in position; when 1 is specified, this function is enabled. It is used to dress other external circles with external circle of the measuring instrument as the reference coordinate system

Note

I. For the situation that measuring instrument is used, when the corresponding technology in-position signal is detected during G77 execution, the block skip is executed to terminate currently executing of G77 and system continues to execute the next line of G code. If G77 is executed when there is measuring instrument failure, when the theoretical size is in position actually, system will continue to perform 1mm more grinding amount and then stop further grinding, and the X axis will move back to the zero point. For the situation that measuring instrument is not used, system performs the feed according to the specified commands.

II. Re-grinding with measuring instrument. During the G77 execution, if there is a corresponding signal of grinding stage after measuring instrument extends, use the X_ command coordinates and speed corresponding to this stage to complete this stage, and then proceed to the next stage of grinding to automatically perform re-grinding. For example, if there is a signal of the P1 roughing stage after measuring instrument extends, use the X coordinates and feed rate of the finishing stage to complete the roughing, and perform G77X_P2 of semi-finishing stage.




Path of grinding wheel in cross grinding (single-time plunge grinding)

- (1) The grinding wheel moves to original grinding position 1;
- (2) Rough grinding: The grinding wheel moves from position 1 to position 2;
- (3) Semi-fine grinding: The grinding wheel moves from position 2 to position 3;
- (4) Fine grinding: The grinding wheel moves from position 3 to position 4;
- (5) Polishing: The grinding wheel stays at position 4;
- (7) Grinding wheel retracts: The grinding wheel moves from position 4 to position 5.

Example

As shown below. The workpiece has three plummer blocks, which include plummer block 1, plummer block 2 and plummer block 3 from right and left. Plummer block 1: workblank diameter is 48.2mm, final diameter is 48mm, length is 30mm; plummer block 2: workblank diameter is 53.1mm, final diameter is 53mm, length is 40mm; plummer block 3: workblank diameter is 58.3mm, final diameter is 58mm, length is 40mm. Width of grinding wheel is 42mm.



%0709;;	
M46;	Start the oil pump
M33	Start the grinding wheel

M7;	Enable cooling
M3 S800	Start the headstock
Determine whether the grinding wheel needs dressed	
IF #54100 EQ #54101	Determine whether the grinding wheel needs dressed
T0102	Confirm to dress coordinate system of the grinding wheel and select offset of tool 2
G1 X10 F1000	The diamond pen nib is 10mm from outside edge of the grinding wheel
Z0	The diamond pen nib is 0mm from end face of the grinding wheel
G1 X1	Move to the position 1mm in rapid traverse
G1 X0 F100	G1 mode, low-speed feed to X0 position
G79I-0.05 Z43 E100F400 N2	Call G79 dressing wheel canned cycle
G1 X10 F100	The grinding wheel retracts to X10 position
#54000=0	The auxiliary variable of wheel dressing: number of grinding workpieces is cleared to enter the next cycle determination
ENDIF	
Start workpiece machining, grinding of plummer block 1	
T0101	Confirm the workpiece coordinate system
G1 Z0 F1000	The grinding wheel moves to Z0 end face of the workpiece coordinate system
G1 X49 F500	Move to diameter X49 at G1 speed
G1 X48.2 F10	Move to the workpiece surface at low speed
G1 X48.15 F0.5	Grind to X48.15 and the measuring instrument stretches
M12	The measuring instrument stretches
G77 X48.1 F0.4 P1	G77 cross grinding canned cycle--rough grinding
G77 X48.05 F0.4 P2	G77 cross grinding canned cycle--semi-fine grinding
G77 X48.02 F0.2 P3	G77 cross grinding canned cycle--fine grinding
G77 X48 F0.1 P4	G77 cross grinding canned cycle--polishing
G04 X1	Dwell 1S
M13	The measuring instrument retracts
G1 X80 F1000	The grinding wheel retracts to X80
Plummer block 2	
Z-40	Z moves right to Z-70, start grinding plummer block 2
X53.3	The wheel moves to the diameter X53.5 position in rapid traverse
X53.2 F50	Move close to the blank surface
X53.1 F5	Move to the blank surface at low speed
G1X53.05F0.4	Rough grinding
G1X53.02F0.2	Semi-fine grinding

G1X53F0.1	Fine grinding
G04X2	Dwell 2s, polishing
G1X80F1000	The grinding wheel retracts
Plummer block 3	
Z-80	Z moves right to Z-80, start grinding plummer block 3
X58.3 F100	Move close to the blank surface
G1X58.1 F5	Move to the blank surface at low speed
G1X58.05 F0.4	Rough grinding
G1X58.02 F0.2	Semi-fine grinding
G1X58F0.1	Fine grinding
G04X2	Pause 2s, polishing
G53G0X0	Return to zero point on X axis
#54000=#54000+1	Auxiliary wheel dressing: the number of ground workpieces is increasing successively
M30	

Multi-times plunge grinding: G77 X (U) _ F_ P_ A_ O_ B_ C_ W_

X (U) — X is the target coordinate value. G90 is the absolute programming mode, and G91 is the incremental programming mode. U is a value relative to start point of grinding, and \pm represents directions. (Diameter programming is by default. If it needs to be modified, modify diameter/radius mode in system parameters)

F — Feedrate of grinding wheel (X direction).

P — Measuring instrument signal. If P value is set, it means that the measuring instrument is used; otherwise, it means that measuring instrument is not used. P1 represents the rough grinding in-position signal. P2 represents the semi-fine grinding in-position signal. P3 represents the fine grinding in-position signal. P4 represents the dimension signal.

A — A: When no value is specified, establish workpiece coordinate system using T0101. When the value is 1, establish workpiece coordinate system using G54 mode.

O — Whether the coordinate system is corrected after the measuring instrument dimension arrival signal is triggered. When no value is specified, coordinates are not corrected after the dimension is in position; when 1 is specified, this function is enabled. It is used to dress other external circles with external circle of the measuring instrument as the reference coordinate system.

B — Width of grinding wheel (mm). When no value is specified, this function is invalid.

C — The amount of overlap of the grinding wheel movement on Z (unit: mm). When no value is specified, this function is invalid.


W — Target coordinate on Z. It is the value relative to the grinding start point. \pm represents the movement direction on Z. When no value is specified, this function is invalid.

Note:

I. For the situation that measuring instrument is used, when the corresponding technology in-position signal is detected during G77 execution, the block skip is executed to terminate currently executing of G77 and system continues to execute the next line of G code. If G77 is executed when there is measuring instrument failure, when the theoretical size is in position actually, system will continue to perform 1mm more grinding amount and then stop further grinding, and the X axis will move back to the zero point. For the situation that measuring instrument is not used, system performs the feed according to the specified commands.

II. Re-grinding with measuring instrument. During the G77 execution, if there is a corresponding signal of grinding stage after measuring instrument extends, use the X_ command coordinates and speed corresponding to this stage to complete this stage, and then proceed to the next stage of grinding to automatically perform re-grinding. For example, if there is a signal of the P1 roughing stage after measuring instrument extends, use the X coordinates and feed rate of the finishing stage to complete the roughing, and perform G77X_P2 of semi-finishing stage.

III. After multi-time plunge grinding is completed, the grinding start point on Z is returned to completed G77, and execute the next line of G codes.



Path of grinding wheel in multi-times plunge grinding (longitudinal grinding)

- (1) G77 canned cycle, the grinding wheel moves to original grinding position X_D;
- (2) G77 canned cycle, the grinding wheel moves from position X_D to position X_C for the first time;
- (3) G77 canned cycle, the grinding wheel moves from position X_D to position X_C many times;
- (4) G76 canned cycle, the grinding wheel moves from position Z_D to position Z_M.

Example

T0101	Determine the workpiece coordinate system
G1 Z0 F1000	The wheel moves to the Z0 end face position of the workpiece coordinate system
G1 X49 F500	Move to X49 ast G1 speed
G1 X48.5 F50	Move close to the blank surface

G1 X48.2 F2	Move to the blank surface at low speed
G1 X48.15 F0.5	Grind to X48.15, and extend the measuring instrument
M12	Extend the measuring instrument
G77X48.1 W100 B50 C10 F0.4 P1	G77 grind multiple times to the rough grinding signal stage
G76 X48.05 Z100 R0.01 E0.2 F400 P2	G76 semi-fine grinding
G76 X48.02 Z100 R0.002 E0.1 F400 P3	G76 fine grinding
G76 X48. Z100R0.001 E0.1 F400 P4	G76 polishing
G04 X1	Dwell 1 second
M13	Measuring instrument returns
G1 X80 F1000	The wheel retracts to X80
M30	

G77 multi-times plunge grinding+G76 longitudinal grinding canned cycle greatly simplifies machining program, and G31 block-skip is not needed

3.1.2 Longitudinal Grinding

G76 X (U) _ Z(W)_ R_ E_ F_ P_ A_ D_ O_ Q_

X (U) — X is the target coordinate value. G90 is the absolute programming mode, and G91 is the incremental programming mode. U is a value relative to start point of grinding, and \pm represents directions. (Diameter programming is by default. If it needs to be modified, modify diameter/radius mode in system parameters)

Z (W) — The target coordinate value on Z, the distance the wheel moved in Z direction. G90 is the absolute programming mode, and G91 is the incremental programming mode. W is a value relative to start point of grinding, and \pm represents directions. (It is best to take the grinding starting point of the edge of the workpiece as the datum)

R — Grinding amount. Unit: mm. Generally, parameters can be set as follows: rough grinding: 0.05; semi-fine grinding: 0.03; fine grinding: 0.02, polishing: 0.01. Specific setting should be based on customer's technological requirements.

E — Feedrate of grinding wheel (X direction).

F — Feedrate of grinding wheel (Z direction).

P — Measuring instrument signal. When P value is specified during programming, it means that the measuring instrument is used; otherwise, it means that the measuring instrument is not used.

P1 represents the rough grinding in-position signal. P2 represents the semi-fine grinding in-position signal. P3 represents the fine grinding in-position signal. P4 represents the final dimension arrival signal.

A — When no value is specified, establish workpiece coordinate system using T0101. When the value is 1, establish workpiece coordinate system using G54.

D — When no value is specified, bilateral feed is by default; when 1 is specified, it means lateral feed.


O — Whether the coordinate system is corrected after the measuring instrument dimension arrival signal is triggered. When no value is specified, coordinates are not corrected after the dimension is in position; when 1 is specified, this function is enabled. It is used to dress other external circles with external circle of the measuring instrument as the reference coordinate system.

Note

I. For the situation that measuring instrument is used, when the corresponding technology in-position signal is detected during G76 execution, the block skip is executed to terminate currently executing of G77 and system continues to execute the next line of G code. If G76 is executed when there is measuring instrument failure, when the theoretical size is in position actually, system will continue to perform 1mm more grinding amount and then stop further grinding, and the X axis will move back to the zero point. For the situation that measuring instrument is not used, system performs the feed according to the specified commands.

II. Re-grinding with measuring instrument. During the G76 execution, if there is a corresponding signal of grinding stage after measuring instrument extends, use the X_ command coordinates and speed corresponding to this stage to complete this stage, and then proceed to the next stage of grinding to automatically perform re-grinding. For example, if there is a signal of the P1 roughing stage after measuring instrument extends, use the X coordinates and feed rate of the finishing stage to complete the roughing, and perform G77X_P2 of semi-finishing stage.


III. For the situation that measuring instrument is used, when the bilateral grinding is executed, in order to ensure the last step of feed at the measuring instrument end and prevent the final size from being small, the G76P4 polishing stage is of the lateral grinding mode.



In the above figure, FF' represents the final size arrival, namely the measuring instrument signaled size reaches the skip position of G31

Example

As shown below. The workpiece has three plummer blocks s, which include plummer block 1, plummer block 2 and plummer block 3 from right and left. Plummer block 1: workblank diameter is 48.2mm, final diameter is 48mm, length is 100mm; plummer block 2: workblank diameter is 53.1mm, final diameter is 53mm, length is 40mm; plummer block 3: workblank diameter is 58.3mm, final diameter is 58mm, length is 40mm. Width of grinding wheel is 42mm.



Grinding wheel

Programming example

%0709;;	
M46;	Start the oil pump
M33;	Start the grinding wheel
M7	Enable cooling
M3S800	Start the headstock
Determine whether the grinding wheel needs dressed	
IF #54100 EQ #54101	Determine whether the grinding wheel needs dressed
T0102	Confirm to dress coordinate system of the grinding wheel and select offset of tool 2
G1 X10 F1000	The diamond pen nib is 10mm from outside edge of the grinding wheel
Z0	The diamond pen nib is 0mm from end face of the grinding wheel
G1 X1	Move to 1mm position in rapid traverse
G1 X0 F100	G1 mode, feed to X0 position at low speed
G79 I-0.05 Z45 E100 F400 N2	Call G79 dressing wheel canned cycle
G1 X10 F100	The grinding wheel retracts to X10 position
#54100=0	The auxiliary variable of wheel dressing: number of grinding workpieces is cleared to enter the next cycle determination
ENDIF	
Start workpiece machining, grinding of plummer block 1	
T0101	Confirm the workpiece coordinate system
G1 Z0 F1000	The grinding wheel moves to Z0 end face of the workpiece coordinate system
G1 X49 F500	Move to diameter X49 at G1 speed
G1 X48.4	
G1 X48.2 F2	Move to the workpiece surface at low speed

G1 X48.17 F0.5	Grind to X48.17 and the measuring instrument stretches
W-58	
W58	
M12	The measuring instrument extends
G76 X48.1 Z-58 R0.01 E0.4 F400 P1	G76 rough grinding, the tool movement on Z is the workpiece size minus the wheel width
G76 X48.05 Z-58 R0.01 E0.2F400 P2	G76 semi-fine grinding
G76 X48.02 Z-58 R0.005 E0.1F400 P3	G76 fine grinding
G76 X48 Z-58 R0.005 E0.1 F400 P4	G76 polishing
G04 X1	Dwell 1S
M13	The measuring instrument retracts
G1 X80 F1000	The grinding wheel retracts to X80
Plummer block 2	
Z-140	Z moves right to Z-140 position, start grinding plummer block 2
X53.3	
X53.2 F10	
X53.1 F2	
G1 X53.05 F0.4	Rough grinding
G1 X53.02 F0.2	Fine grinding
G1 X53 F0.1	Polishing
G04 X2	Dwell 2s, the size arrives
G1 X80 F1000	The grinding wheel retracts
Plummer block 3	
Z-180	Z moves right to Z-180 position, start grinding plummer block 3
X58.3	
G1 X58.3F100	
G1 X58.1 F2	
G1 X58.05 F0.4	Rough grinding
G1 X58.02 F0.2	Fine grinding
G1 X58 F0.1	Polishing
G04 X2	Dwell 2s, the size arrives
G53 G1 X0 F1000	Return to zero point on X
#54100=#54100+1	Auxiliary wheel dressing: the number of ground workpieces is increasing successively
M30	

3.1.3 Grinding Wheel Dressing

G79 I_Z_E_F_N_Q_A_D_

Interpretation:

I — Single dressing of grinding wheel. Generally the I value is negative.

Z — Coordinate value. Generally it refers to movement distance in Z direction (exceeding thickness of grinding wheel). Z may be positive or negative. Actually, displacement distance in Z direction should add up to thickness $\pm 3\text{MM}$ of grinding wheel in the grinding system.

E — Feedrate of grinding wheel in X direction.

F — Movement speed of worktable in Z axis.

N — Grinding wheel dressing times.

Q — Whether returns to the starting point of grinding after program ends.


When no value is specified: Yes;


when 1 is set: No.

A — A: When no value is specified, establish workpiece coordinate system using T0102. When the value is 1, establish workpiece coordinate system using G54 mode.

D — Lateral/bilateral feed selection. Bilateral by default. 1: Lateral feed.

K — Dressing composition coefficient. The coordinate system compensation amount is equal to the dressing amount multiplied by the coefficient; when 1 is specified, the workpiece coordinate system is established in G54 mode.



**Note**

- I. During wheel dressing, I and F, N values can be set to determine whether to use the roughing or finishing.
- II. The number of grinding workpieces can be set to reach the set value for grinding wheel dressing. Variable #53990 records the number of workpiece grinding times, #53991 dressing the grinding wheel every time how many workpieces are ground, and when #53990 is equal to #53991, the grinding wheel dressing is performed

Example

Program of grinding wheel dressing

%5930	
IF [#53990 EQ #53991]	Wheel dressing will be performed if workpiece grinding times reaches the set value
T0102	Conform the coordinate system of grinding wheel dressing
M33	Enable the grinding wheel
M7	Turn on cutting fluid
G1 X10 F500	The grinding wheel moves to 10mm from diamond pen nib
G1 X2	
G1 X0 F10	The grinding wheel moves to X0
Z0	The worktable moves to Z0
G79 I-0.01 Z55 E10F100 N2	Execute G79 command
G1 X10	Retract
M9	

M34	Disable the grinding wheel
#53990 = 0	Number of ground workpieces is cleared after the wheel is dressed
ENDIF	
M30	

3.1.4 End Face Positioning

G80 W_E_F_H_J_A_

W — The distance from the starting point of measurement to the probe (generally it is the tool setting point of workpiece end face measurement T0103 coordinate system) in Z direction while positioning the end face to the fault point of the measuring instrument. Moving this distance in the Z direction must ensure that the measuring instrument signal can be triggered. \pm represents the direction of movement in the Z direction.


E — The first positioning speed, feedrate on Z.

F — The second positioning speed, feedrate on Z.

H — The allowable maximum measurement error. When this value is exceeded, the coordinate system is not performed and the system alarm. When no value is specified, 0.5mm is the default.

J — The retract distance after the measurement instrument signal is triggered for the first positioning. It is a positive value, in the unit mm.

A — A: When no value is specified, establish workpiece coordinate system using T0101. When the value is 1, establish workpiece coordinate system using G5.





For G80 end face positioning, if the zero point of tool 1 (the workpiece grinding coordinate system zero on Z) has been set, #53998 must be changed to 1 manually. Then when G80 is executed for the first time, the system will assign the tool 1 zero point on Z to the #53999 variable and store it as the Z-direction reference; and use the Z-direction position of the second trigger signal of the end-face measuring instrument as the T0103 coordinate system zero on Z, then set #53998 to zero. Later, when executing G80, the difference between the second trigger signal Z-direction position of the end face measuring instrument and the Z-direction zero point of T0103 coordinate system will be superimposed to the reference as the T0101 coordinate system zero on Z.

Note

G80 end face positioning is based on the Z-direction zero point of the first workpiece (blank) T0101 coordinate system as the reference, and the Z-direction zero point of the subsequent workpiece as the reference plus the deviation measurement value. The reference is stored in variable #53999, and the batch processing datum remains unchanged to ensure that the measurement deviation will not accumulate. If the workpieces is changed and tool setting is performed again, due to the reference change, the variable #53998 must be changed to 1 to re-set the reference.

End face positioning program

%111	
T0103	End face measurement coordinate system
M46	Start the oil pump

M16	The measuring instrument stretches
G1 X100 F1000	The grinding wheel moves
Z100	
X50	
Z4	The worktable moves to the right position
G80 W-5 E50 F5 H1 J0.5	Call G80
M17	The measuring instrument retracts
G1 X100 F1000	
M30	

3.1.5 Wheel End face Dressing

G81 X(U)_Z(W)_E_F_N_


X (U) -- Dressing depth on X

Z (W) -- Feed amount on Z

E -- Feedrate on X

F -- Feedrate on Z

N -- Dressing times. When no value is specified, the default is 1.



Note

- ① The coordinate system of grinding wheel end face dressing is T0104.
- ② When using end face grinding, the wear of the end face of the grinding wheel is lower than that of the outer circle, and the frequency of dressing the end face is generally lower than that of the outer circle. Users can set the end face dressing after the outer circle dressing reaches the set number of times.

Example

%I234	
T0104	The wheel end face dressing coordinate system
M33	Enable the wheel
M7	Enable the cutting fluid
G1 X10 F500	The wheel moves to the 10mm position from diamond pen nib
G1 X2	
Z0	Worktable moves to Z0
G1 X0 F10	Wheel moves to X0
G81 U30 W0.02 E50 F10	Execute G81
G1 X10	Retract
M9	
M34	Disable the wheel
M30	

3.2 Process Card

3.2.1 Commonly Used Parameters

	机床实际	工件实际	剩余进给
X	-0.030	-0.026	0.000
Z	-2.999	-3.007	0.000
C	280.692	0.000	0.000

常用参数	
快移定位速度	1000.000
砂轮修整后工件数	0
待修整砂轮前的磨削工件数量	10
砂轮外圆的修整次数	0
外圆修多少次,修整一次端面	0
轴台数目	3
磨削哪个轴台后修砂轮(多轴...	0
头架转速	200.000
砂轮耗损补偿量	0.000

参数说明:
设定单次磨削工件砂轮损耗量(mm),范围-2-0

Commonly used parameter list:

Contents of parameters	Setup description
Rapid traverse positioning speed	Feedrate in rapid traverse positioning, unit: mm/min
Number of ground workpieces after wheel dressing	The initial value is 0. The number of ground workpieces after wheel dressing. It is cleared automatically after dressing.
Number of ground workpieces before wheel dressing	Number of the ground workpieces. When the actual number reaches the set value, the wheel will be dressed automatically.
Number of dressing of the wheel outer-circle	Number of times that the outer circle of wheel is dressed. It is set to 0 after wheel end face is dressed
How many times the outer circle of the grinding wheel is dressed every time the end face is dressed	To set How many times the outer circle of the grinding wheel is dressed every time the end face is dressed
Number of plunger blocks	Set the number of plunger blocks to be ground, 4 at most
Headstock speed	Set the speed of servo headstock and frequency conversion headstock. Unit: r/min
Wheel wear compensation amount	Set the wear of wheel for single grinding (mm), ranges from -2 to 0

3.2.2 Parameters Of Grinding Wheel

参数说明:
设定单次磨削工件砂轮损耗量(mm),范围-2-0

机床实际	工件实际	剩余进给	
X	-0.030	-0.026	0.000
Z	-2.999	-3.007	0.000
C	280.692	0.000	0.000

常用参数

快移定位速度	1000.000
砂轮修整后工件数	0
待修整砂轮前的磨削工件数量	10
砂轮外圆的修整次数	0
外圆修多少次,修整一次端面	0
轴台数目	3
磨削哪个轴台后修砂轮(多轴...	0
头架转速	200.000
砂轮损耗补偿量	0.000

Basic parameters:

Contents of parameters	Setup description
Grinding wheel width	Width of grinding wheel. Unit: mm
Wheel real-time diameter	Real-time diameter of wheel. Unit: mm
Minimum failure diameter of wheel	The minimum diameter of wheel. Unit: mm
Constant linear speed Enable	0: is disabled; 1: is enabled. Frequency conversion wheel is valid
Constant linear speed (m/s)	Unit: m/s
Speed corresponding to linear speed (r/min)	It is the monitoring value



Dress technology

Contents of parameters	Setup description
Whether to dress the grinding wheel	0: dress the wheel automatically in machining; 1: dress the wheel separately
Dressing direction	-1: from left to right; 1: from right to left. Determine based on the first tool moving direction
Lateral/Bilateral dressing	0: lateral; 1: bilateral. Note: it must be 1 when dressing the end face
Rapid safe position on X	Generally can be set as 1 to 5mm
Rapid safe position on Z	Defaulted 1mm. Set based on the actual requirements
Dressing start point return speed	From the safe position set above to the position of X0Z1 or X0Z-1, the corresponding F value
X-direction distance of start point return	Retract distance on X after dressing, diameter, unit: mm. The lateral dressing is valid.
Single-step amount in roughing on X	Set based on the actual requirements
Roughing speed on X	
Roughing speed on Z	
Roughing times	
Single-step amount in finishing	Set based on the actual requirements

on X	
Finishing speed on X	
Finishing speed on Z	
Finishing times	
coordinate compensation coefficient after wheel dressing	1 is the default. Set based on the actual requirements. Range: 0 to 1; if 0 is set, then the coordinate offset will not be performed after dressing
Start point return speed in lateral dressing	Unit: mm/min

The screenshot displays the HNC-818 control interface for grinding. At the top, it shows 'CH1' and the date/time '2020-09-28 18:13:33'. The main menu includes '手动' (Manual), '程序' (Program), '设置' (Settings), '磨削' (Grinding), '刀补' (Tool Compensation), '诊断' (Diagnosis), and '位置' (Position). A data table on the right shows actual machine, workpiece, and remaining feed values for X, Z, and C axes.

	机床实际	工件实际	剩余进给
X	-0.030	-0.026	0.000
Z	-2.999	-3.007	0.000
C	296.472	0.000	0.000

Below the table is a section for '圆弧/端面参数' (Arc/End Face Parameters) with various settings for left and right end faces, such as '左端面圆弧' (Left end face arc) set to 0.

The central diagram illustrates the grinding process with labels for 'D(砂轮宽度)' (Wheel width), 'N3(光整次数)' (Polishing times), 'N2(精修次数)' (Finishing times), 'N1(粗修次数)' (Rough dressing times), and 'J(Z移动方向)' (Z movement direction). It also shows 'F-X(精磨) F-Z(精磨)' and 'F-X(粗磨) F-Z(粗磨)' stages, along with 'X-B(开始) Z-B(开始)' and 'X-S(安全) Z-S(安全)' points.

At the bottom, there are navigation buttons for '基本参数' (Basic parameters), '修整工艺' (Dressing process), '端面修整' (End face dressing), '异形砂轮' (Specialty wheels), and '异形表格' (Specialty tables).

End face dressing

Contents of parameters	Setup description
Left end face arc	0: Exist; 1: Not exist
Left end face R	Radius of left end face arc
Left end face dressing selection	0: Not dress; 1: Dress
Left end face dressing amount on Z	Dressing amount of left end face on Z. Unit: mm
Left end face dressing depth on X	Dressing depth of left end face on X. Unit: mm

Right end face arc	0: Exist; 1: Not exist
Right end face R	Radius of right end face arc
Right end face dressing selection	0: Not dress; 1: Dress
Right end face dressing amount on Z	Dressing amount of right end face on Z. Unit: mm
Right end face dressing depth on X	Dressing depth of right end face on X. Unit: mm
End face dressing speed	Unit: mm/min

3.2.3 Parameters of Measuring Instrument

机床实际 工件实际 剩余进给

X	-0.030	-0.026	0.000
Z	-2.999	-3.007	0.000
C	289.968	0.000	0.000

量仪参数

端面量仪是否首次对刀	0.000
端面量仪是否使用	0
定位方向选择	-1
量仪触发信号数目	0
X向安全位置(量仪伸出)	0.000
Z向安全位置(量仪伸出)	0.000
X向开始测量位置	0.000
Z向开始测量位置	0.000
快速趋近速度	0.000
粗定位Z向行程	0.000
粗定位Z向速度	0.000

参数说明:
0:单信号, 1个信号完成定位; 1:双信号, 粗、精2个信号

\$1

常用参数 砂轮参数 量仪参数 轴台参数 自定义宏变量 桁架 用户文件 权限管理

Parameter list of measuring instrument:

Contents of parameters	Setup description
Whether tool setting of measuring instrument is for the first time	0: No; 1: Yes. As long as the Z axis of T0101 performs tool setting again, this parameter needs to be manually set to 1
Whether end face measuring instrument is used	0: No; 1: Yes
The probe is on the left/right of the reference level	-1: Probe is on the right of positioning level; 1: Probe is on the left of positioning level


Safe position in X direction (the measuring instrument stretches)	Position where the measuring instrument stretches. Ensure no collision of measuring instrument
Safe position in Z direction (the measuring instrument stretches)	Position where the measuring instrument stretches. Ensure no collision of measuring instrument
Starting point of measurement in X direction	Starting position of probe measuring
Starting point of measurement in Z direction	Starting position of probe measuring
Rapid approach speed	Speed from safe position to measurement position
Rough positioning travel on Z	Larger than the fine positioning travel
Rough positioning speed on Z	Generally, 10 to 20
Fine positioning travel on Z	Smaller than the first Z value
Fine positioning speed on Z	Round F5. This value can affect the measuring precision
Dwell time after signal trigger (ms)	Set based on the actual requirements. Unit: ms. Generally 0 is set
Allowable maximum measuring error	Compensation is not performed when this error is exceeded
Initial offset on Z	It is generated by automatic measurement, and cannot be changed

3.2.4 Parameters Of Plummer Block

参数说明:
0, 不使用; 1, 使用

机床实际	工件实际	剩余进给	
X	-0.030	-0.026	0.000
Z	-2.999	-3.007	0.000
C	315.530	0.000	0.000

公共参数	轴台选项	轴台1
径向量仪是否使用		0
对应几号量仪		1
径向量仪校正X坐标		1
磨削方式		0
纵磨进刀方式		1
纵磨方向		-1
X向安全位置		40.000
Z向安全位置		20.000
X向快趋位置		30.000
Z向快趋位置		20.000
靠近毛坯速度		2000.000



Public parameters

Contents of parameters	Setup description
Whether radial measuring instrument is used	0: No; 1: Yes
Corresponding measuring instrument	1: Radius measuring instrument 1; 2: Radius measuring instrument 2
Radial measuring instrument correction X coordinate	Coordinate origin is corrected based on P4 signal. 0: Not correct; 1: Correct
Grinding mode	0: Plunge grinding; 1: Longitudinal grinding; 2: Multi-times plunge grinding
Safe position on X	Safe position on X
Safe position on Z	Safe position on Z
Rapid approach position on X	Approach workpiece position on X
Rapid approach position on Z	Approach workpiece position on Z
Approaching workblank speed	F value corresponding to G1 from Xpos and Zpos to workblank
Workblank diameter	Grinding diameter, workblank, roughing, semi-finishing, and finishing are values under diameter programming mode
Grinding amount before measuring instrument stretches	
Workpiece diameter after polishing	
Polishing amount	
Finishing amount	

Semi-finishing amount	
Roughing amount	
Whether grind end face	0: No; 1: Yes
Left/Right end face grinding of wheel	0: Left; 1: Right (Facing the wheel)
Z end face grinding amount	This parameter is a positive value. The system automatically judges positive and negative.
Retract amount in end face grinding after polishing	For Z end face grinding, this parameter must be set, and can be set as 0.05 to 0.1
Z end face grinding speed	End face grinding speed. A smaller value is recommended. The end face of the right-angle grinding wheel cannot bear too much grinding force
End face grinding time	Unit: ms

The screenshot displays the HNC-818 CNC control interface. At the top, it shows 'CH1' and the date/time '2020-09-28 18:20:19'. The main menu includes '手动' (Manual), '程序' (Program), '设置' (Settings), '磨削' (Grinding), '刀补' (Tool Compensation), '诊断' (Diagnosis), and '位置' (Position). The '磨削' (Grinding) screen is active, showing a diagram of a grinding wheel and a workpiece with various grinding stages labeled: 黑皮量U0, 粗磨量U1, 半精磨U2, 精磨U3, 光磨U4, F1-粗磨, F2-半精磨, F3-精磨, F4-光磨, and Q磨. A table on the right shows '切入磨参数' (Plunge grinding parameters) for '轴台1' (Spindle 1):

机床实际	工件实际	剩余进给	
X	-0.030	-0.026	0.000
Z	-2.999	-3.007	0.000
C	296.244	0.000	0.000

Below the table, the '切入磨参数' (Plunge grinding parameters) are listed:

参数名称	数值
粗磨x向速度	5.000
半精磨x向速度	4.000
精磨x向速度	3.000
光磨x向速度	2.000
光磨时间(ms)	1000

At the bottom, there is a '参数说明' (Parameter description) section with the unit 'mm/min' and a '\$1' label. The bottom navigation bar includes buttons for '公共参数' (Common parameters), '切入磨' (Plunge grinding), '纵磨' (Vertical grinding), '多次切入' (Multiple plunge), and a right arrow.

Plunge grinding parameter

Contents of parameters	Setup description
Roughing speed on X	Set based on actual requirements. Unit: mm/min
Semi-finishing speed on X	
Finishing speed on X	

Polishing speed on X	
Polishing time (ms)	Unit: ms

CH1 2020-09-28 18:21:57

手动 程序 设置 磨削 刀补 诊断 位置

机床实际	工件实际	剩余进给
X -0.030	-0.026	0.000
Z -2.999	-3.007	0.000
C 280.731	0.000	0.000

纵磨参数 轴台选项 轴台1

台阶宽度	0.000
粗磨单步量	0.000
半精磨单步量	0.000
精磨单步量	0.000
光磨单步量	0.000
粗磨Z向速度	0.000
半精磨Z向速度	0.000
精磨Z向速度	0.000
光磨Z向速度	0.000
磨削后是否修整砂轮	0
X向单边磨后退距离	0.000

○ : 当前工件轴台长度

X-S(安全), Z-S(安全)
X-R(快趋), Z-R(快趋)

黑皮量
粗磨
半精磨
精磨
光磨

D1左轴程距离 D2右轴程距离
L轴台长度

参数说明:

\$1

公共参数 切入磨 纵磨 多次切入



Longitudinal grinding parameter:

Contents of parameters	Setup description
Feed mode	1: Lateral; 0: bilateral feed
Longitudinal grinding direction	1: Movement in positive Z; -1: Movement in negative Z
Step width	Under the same diameter, the actual size of plummer block in Z direction, also the drawing size
Single-step amount of roughing	Values calculated according to diameter values in the public parameters
Single-step amount of semi-finishing	
Single-step amount of finishing	
Single-step amount of polishing	
Roughing speed on Z	Set based on actual requirements. Unit: mm/min
Semi-finishing speed on Z	
Finishing speed on Z	
Polishing speed on Z	
Whether to dress the grinding wheel after grinding	Judge whether it is necessary to dress the grinding wheel after roughing, semi-finishing and finishing. For specific value, refer to parameter annotation
Retract distance on X after lateral grinding	Used for lateral grinding. If it is 0, return to the starting point of grinding along Z axis against the surface of the outer diameter ground last time

Dwell time Left (ms)	The process requires a pause at both ends for a period of time
Dwell time Right (ms)	
Polishing times	After the set size is reached through polishing, horizontal polishing times in Z direction, and not feed in X direction. If polishing is enabled, it is better to increase polishing size slightly
Overtravel distance Left	The distance that the wheel end face exceeds the plummer block end face to be ground
Overtravel distance Right	

	机床实际	工件实际	剩余进给
X	-0.030	-0.026	0.000
Z	-2.999	-3.007	0.000
C	278.509	0.000	0.000

多次切入参数轴台选项: 轴台1

切入磨到哪个阶段	0
切入纵磨方式	0
Z向重叠距离	0.000
切磨返回起点后退距离	0.000
X向单次切入后回退量	0.000
单次切入后回退速度	0.000
切磨走刀粗磨后数值	0.000


参数说明:
0:粗磨; 1:半精磨; 2:精磨; 3:光磨


Multi-times plunge grinding parameter

Contents of parameters	Setup description
Stage of plunge grinding	0: Roughing; 1: Semi-finishing; 2: Finishing; 3: Polishing
Plunge grinding mode	Reuse retract amount of crush grinding. Example: Suppose crushing grinding is adopted for coarse grinding and feed grinding is adopted for medium grinding and accurate grinding. Meaning of the parameter: Ensure no collision during crush grinding based on retract amount based on workblank diameter
Z-direction overlap distance	Retract speed

Retract distance after returning to start point	
Retract amount after X single plunge	The retraction amount when plunge grinding is used cyclically. Example: If plunge grinding, semi-finishing, and finishing are used for roughing, and Z-direction grinding is used for polishing, then the meaning of this parameter is: the amount of retraction based on the diameter of the blank to prevent the collision when cutting into the cycle
Retract speed after single plunge	Retract speed
	The value is used for monitoring

3.2.5 Custom Macro Variable






Users can use the custom macro variables provided by the system to program, and can edit the custom macro variables including the types and meanings of the macro variables.

- Customized macro variable editing

(1) Press Set, select Data Manage menu, select User Macro Configuration File under the "Data Management" submenu, insert the U disk, and select USB, as shown in the figure below:



(2) Press the up and down direction keys to confirm the custom macro variable XML configuration file that needs to be edited, and select Load to back up the custom macro variable to the U disk.

Custom macro variables 1 to 9 correspond to USERMACCFG0.XML~USERMACCFG8.XML.

(3) Open the custom macro configuration file with an editing tool for editing

```

1  <?xml version="1.0" encoding="GB2312"?>
2  <USERMACCFG version="1.0">
3
4  <item no = "54000" name = "自定义" type= "FLOAT" min="-9999" max="9999"></item>
5  <item no = "54001" name = "自定义" type= "FLOAT" min="-9999" max="9999"></item>
6  <item no = "54002" name = "自定义" type= "FLOAT" min="-9999" max="9999"></item>
7  <item no = "54003" name = "自定义" type= "FLOAT" min="-9999" max="9999"></item>
8  <item no = "54004" name = "自定义" type= "FLOAT" min="-9999" max="9999"></item>
9  <item no = "54005" name = "自定义" type= "FLOAT" min="-9999" max="9999"></item>
10 <item no = "54006" name = "自定义" type= "FLOAT" min="-9999" max="9999"></item>
11 <item no = "54007" name = "自定义" type= "FLOAT" min="-9999" max="9999"></item>
12 <item no = "54008" name = "自定义" type= "FLOAT" min="-9999" max="9999"></item>
13 <item no = "54009" name = "自定义" type= "FLOAT" min="-9999" max="9999"></item>
14
15 </USERMACCFG>
16

```

no = "54000", the content in " " is the macro variable number; name = "自定义", the content in " " is the macro variable meaning;

type= "FLOAT", the content in " " is the macro variable type, FLOAT is a floating-point variable, and INT is an integer variable;

min="-9999", the content in " " is the minimum value of macro variable; max="9999", the content in " " is the maximum value of macro variable.

Note

① The custom macro variables that can be used by users are #53000 to #54999.

②The format of the custom macro variable XML table cannot be changed. The content in " " is the content that can be modified by the user, and other parts are not allowed to be modified.

(4) After configuring the XML form, use the U disk to "load" into the system according to the above operation, and it will take effect after power off and restart.